




# SERVICE PARTS LIST

**BULLETIN NO.**  
**PN0007979**

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN	DATE
<b>M18 FUEL™ 7-1/4" Circular Saw w/ One-Key™</b>			July 2025
CATALOG NO.	<b>2835-20</b>	SERIAL NO.	<b>R17A</b>
		WIRING INSTRUCTION <b>See Page 4</b>	

00  
0

**EXAMPLE:**  
Component Parts (Small #)  
Are Included When Ordering  
The Assembly (Large #).



**SEE PAGE 3 FOR  
SERVICE NOTES AND  
THE LUBRICATION  
OF THIS TOOL**

## SERVICE BOM LISTING

FIG. PART NO.	DESCRIPTION OF PART	NO. REQ.	FIG. PART NO.	DESCRIPTION OF PART	NO. REQ.
1	Flange Bolt	(1)	59	Switch Lock Button	(1)
2	Outer Flange	(1)	60	23-66-0116 Switch	(1)
3	43-34-0790 Inner Flange	(1)	60b	Switch Screws (Not Shown)	(2)
4	External Retaining Ring	(1)	62	Handle Cover	(1)
5	31-15-9005 Sleeve Ring	(1)	63	06-82-7470 #6-19 17mm Torx T-15 Screw	(9)
7	06-82-5285 #6-32 T-15 Pan Hd. Screw	(6)	64	Flat Washer	(1)
8	Spindle Lock Cover	(1)	65	Depth Shaft	(1)
9	45-06-1260 Felt Seal	(1)	66	Depth Adjustment Lever	(1)
10	40-50-8046 Spindle Lock Spring	(1)	67	05-74-7190 M3.5 x 30mm Pan Hd. Torx T-10 Screw	(2)
11	Spindle Lock Plate	(1)	68	Front Pommel	(1)
12	Output Gear Sub-Assembly	(1)	69	05-78-0032 M5 x 13mm Machine Screw	(1)
16	45-04-0485 M4 x 19.8mm PH Torx T-20 Taptite Screw	(1)	70	M2 x 10mm Pan Hd. Torx T-6 B Screw	(1)
17	42-38-0224 Rubber Bumper	(1)	74	50-55-3560 Contractor Bag (Accessory)	(1)
18	Pivot Shoulder Bolt	(1)	75	48-40-0740 Circular Saw Blade (Accessory)	(1)
19	Upper Guard Gearcase	(1)	76	12-20-2805 Service Nameplate	(1)
20	M6 x 6mm Hexagon Nut	(1)	77	10-22-3007 Warning Label (#2)	(1)
21	Spindle Lock Button	(1)	78	05-78-5320 M2.3 x 5mm Pan Hd. Torx T-8 Screw	(1)
22	06-82-5314 #10-24 Pan Hd. Torx T-25 Taptite Screw	(1)	79	Flat Washer	(3)
23	Lower Guard Lever	(1)	80	06-82-0248 M3 x 16.5mm FH Phillips #2 B ST Screw	(2)
24	Lower Guard	(1)	81	28-20-0038 Coin Cell Battery Cover	(1)
25	49-68-5212 Spring	(1)	83	M2 x 5mm T-8 PT Screw	(3)
26	05-78-1005 M3.5 x 12mm Philips M Screw	(1)	84	Vaclink OneKey UI Panel	(1)
27	14-20-0415 Dust Port	(1)	85	Vaclink OneKey UI Button	(1)
29	06-10-0110 Carriage Bolt (Short Neck)	(1)	86	06-82-7475 #6-19 Torx T-15 PH L=.875" ST Screw	(1)
31	Hexagon Nut	(1)	87	10-22-3006 Warning Label (#1)	(1)
32	Bowed E-Ring	(1)	88	10-15-9730 ID Label	(1)
33	Depth Adjustment Knob	(1)	100	31-44-0323 Handle Kit	(1)
34	Washer	(1)	101	14-46-9961 Dust Tube Kit	(1)
35	06-10-0025 M6 x 1 Bevel Machine Screw	(1)	102	14-46-9962 Spindle Lock Kit	(1)
36	Shoe Assembly	(1)	103	14-47-1270 Output Gear Assembly	(1)
37	40-50-0650 Rip Fence Spring	(1)	104	14-46-9963 Gearcase Kit	(1)
38	Rip Fence Knob	(1)	105	14-20-0404 PCBA & Stator Assembly	(1)
39	45-88-9320 Blade Bolt Wrench	(1)	106	45-16-3260 Shoe Kit	(1)
40	O-Ring	(1)	107	16-01-6530 Rotor Assembly	(1)
44	05-74-1030 M5 x 12mm Torx T-25 Pan. Hd. Screw	(2)	108	14-46-9965 Plunge Lever Kit	(1)
45	Rotor Sub-Assembly	(1)	109	14-46-9966 Blade Retention Kit	(1)
46	05-78-1010 M3.5 x 12mm Pan Hd. Torx T-10 Screw	(2)	110	14-46-9968 Lock-Off Trigger Kit	(1)
47	42-32-0028 M4 x 70mm Pan Hd. Torx T-20 Screw	(3)	111	31-44-0325 Pommel Kit	(1)
50	06-82-0243 M2 x 6mm Torx T-6 PT Screw	(3)	112	49-22-9940 Rip Fence Kit	(1)
51	06-82-9637 M6 x 28mm Pan Hd. Torx T-30 Screw	(2)	113	14-46-9967 Rafter Hook Assembly	(1)
57	Handle Support	(1)	114	28-41-2040 Lower Guard Assembly	(1)
58	Button Flake	(1)	115	31-44-0344 UI Kit	(1)

## SCREW TORQUE SPECIFICATIONS

FIG. PART NO.	DESCRIPTION OF FASTENER	QTY	WHERE USED	SEAT TORQUE	
				(kgf-cm)	(lb-in)
1	Flange Bolt	1	For Flange	10 ± 1	9 ± 1
7	06-82-5285 #6-32 T-15 Pan Hd. Screw	6	For Outhub and Spindle Lock Cover	17 ± 3	15 ± 2.6
16	45-04-0485 M4 x 19.8mm PH Torx T-20 Taptite Screw	1	For Rubber Bumper	35 ± 4	30 ± 3.5
18	Pivot Shoulder Bolt	1	For Bevel Pivot	22 ± 2	19 ± 1.7
22	06-82-5314 #10-24 Pan Hd. Torx T-25 Taptite Screw	1	For Lower Guard Lever	35 ± 4	00 ± 3.5
31	Hexagon Nut	1	For Bevel	22 ± 2	19 ± 1.7
44	05-74-1030 M5 x 12mm Torx T-25 Pan. Hd. Screw	2	For Bearing Retainer Plate	30 ± 3	26 ± 2.6
46	05-78-1010 M3.5 x 12mm Pan Hd. Torx T-10 Screw	2	For Right Handle	10 ± 1	9 ± 1
47	42-32-0028 M4 x 70mm Pan Hd. Torx T-20 Screw	3	For Stator	18 ± 2	16 ± 1.7
50	06-82-0243 M2 x 6mm Torx T-6 PT Screw	3	For Hall Board	2.5 ± 0.3	2.2 ± 0.3
51	06-82-9637 M6 x 28mm Pan Hd. Torx T-30 Screw	2	Ror Rafter Hook Bracket	25 ± 3	22 ± 2.6
60b	Switch Screws	2	For Switch	10 ± 1	9 ± 1
63	06-82-7470 #6-19 17mm Torx T-15 Screw	9	For Left Handle	11 ± 1	10 ± 1
65	Depth Shaft	1	For Depth Shaft	40 ± 4	35 ± 3.5
67	05-74-7190 M3.5 x 30mm Pan Hd. Torx T-10 Screw	2	For Left Handle	13 ± 2	11 ± 1.7
69	49-16-2718 M5 x 13mm Machine Screw	1	For Depth Lever	30 ± 3	26 ± 2.6
70	M2 x 10mm Pan Hd. Torx T-6 B Screw	1	For Worklight	2.8 ± 0.3	2.4 ± 0.3
78	05-78-5320 M2.3 x 5mm Pan Hd. Torx T-8 Screw	1	For Left Handle	1.6 ± 0.5	1.4 ± 0.4
80	M3 x 16.5mm FH Phillips #2 B ST Screw	2	For Coin Cell Battery Cover	4.5 ± 0.3	3.9 ± 0.3
83	M2 x 5mm T-8 PT Screw	3	For UI Panel	2.4 ± 0.3	2.1 ± 0.3
86	06-82-7475 #6-19 Torx T-15 PH L=.875" ST Screw	1	For Pommel	14 ± 2	12 ± 1.7


## LUBRICATION INSTRUCTIONS

### ► Type "J" Grease

No. 49-08-4220, 1 lb can


Apply thin coat of grease to areas indicated.

**NOTE:** When servicing, remove 90-95% of the existing grease prior to installing Type "J". Original grease may be similar in color but not compatible with "J".




Apply about 0.2 g of Grease on the Knob Thread (38)

Apply about 4.5 ~5 g of Grease on the surface of the Upper Guard Gearcase (19)



Apply about 0.05 g of Grease on the surface of the O-Ring (40)





Apply about 2 ~2.5 g of Grease on the surface of the Gear and Output Shaft (12)

## WIRING DIAGRAM

### IMPORTANT:

- **Strong magnetic force.** Care must be taken when installing the Rotor Assembly (107) into the Stator Assembly. Do not allow rotor bearing or balancing bushing to hit PCBA on the back end of the stator. This could cause damage to the PCBA.
- Insert the rotor/stator assembly into pinion bore of the Upper Guard Gearcase Assembly (19). Carefully wiggle and push the rotor/stator until the ball bearing in front of the fan is fully seated in the bearing bore of the gearcase.

 = WIRE TRAPS or GUIDES



# HOW TO REPLACE THE ELECTRONICS ASSEMBLY (FIG.105)

NOTE: Tool model 2834-20 shown in pictures




Remove two T-30 screws (fig.51) from rafter hook assembly.




Remove T-25 screw (fig.69) from inside plunge lever.




Remove from left housing/handle nine T-15 screws (fig.63) circled in yellow, two T-10 screws (fig.67) circled in white and one T-8 screw (fig.78) circled in green.




Remove T-6 screw (fig.70) from LED light with screwdriver.




Remove three T-20 screws (fig.47) from stator.



Firmly grasp the stator with both hands and forcibly pull the stator from the magnetic force of the rotor assembly.



Remove 2 top screws from switch (fig.60) with philips head bit or screwdriver. Detach yellow wires from screws/switch.




Remove old PCBA & Stator assembly and replace with new PCBA & Stator service assembly 14-20-0404 (fig.105).



Follow directions in reverse order to put assembly/tool back together. Be sure there are no interferences and wires are properly placed within traps/channels.

## ASSEMBLING OUTPUT GEAR ASSEMBLY INTO UPPER GUARD GEARCASE

Detail 'A' shows Spindle Lock Spring (10) and Felt Seal (9) in place in the respective cavities of the Upper Guard Gearcase Assembly (19).  
**NOTE:** The spindle hub and gear of the Output Gear Assembly (103) are not shown for clarity, so the four Locking Cogs of the Lock Block can be seen.



To prevent damage to the Felt Seal (9) it is recommended to temporarily remove the felt seal until steps 1 and 2 are completed.

1. With the use of both hands, compress the Spindle Lock Spring (10) back on the Spindle Lock Plate (11) past the small hole on the plate.
2. While holding the spring back with one hand, quickly insert a thin metal instrument into the small hole on the plate. The metal instrument should capture the entire spring (all coils should be behind that tool).

With the spindle lock spring trapped behind the small hole on the spindle lock plate, slide the felt seal back onto the spindle lock plate. Position the felt seal above the corresponding cavity in the Upper Guard Gearcase (19).

3. Insert the open end of the Spindle Lock Plate (11) into the opening of the Output Gear Assembly (103) behind the gear, as shown.

4. Insert the bearing shaft portion of the output shaft assembly into the needle bearing of the upper guard gearcase assembly. Carefully wiggle the entire output shaft assembly until the gearing of the output shaft assembly engages with the pinion gearing of the Rotor (107) and the output shaft assembly slides into place.

Secure the output shaft assembly to the upper guard gearcase assembly with the use of four screws (7), not shown. It is recommended to alternate the tightening of the screws.

5. Remove the thin metal instrument. Check for the proper functioning of the spindle locking mechanism. Rotate the spindle shaft and depress the Spindle Lock Button (21) at the same time. The spindle lock plate should drop into one of four cogs that lock the spindle. Spindle lock mechanism must return briskly when released from engagement in the lock block cog.