

# INSTRUCTION SHEET FOR MODEL SLRK

**TOOLS REQUIRED:** Screw Driver or Power Screw Driver

**STEP 1:** Determine desired length and height of your Log Rack. Cut four (4) 2 x 4's to the desired height to become the four (4) vertical supports. Cut two (2) additional 2 x 4's to the desired length to become the bottom horizontal supports.

**STEP 2:** Carefully remove all contents from the package. The package will contain two (2) End Brackets and a package of twenty (20) screws.

**STEP 3:** Place the End Brackets on the ground with the opening of the "U" shapes facing each other. The distance between them should be approximately the length of the 2 x 4's that are the bottom supports.

**STEP 4:** Insert a vertical support 2 x 4 into the inside corner in one of the End Brackets. While holding the 2 x 4 vertical, insert two (2) screws through the predrilled holes in the End Bracket and tighten to firm up the 2 x 4. Insert two (2) screws into the predrilled holes on the backside of the End Bracket and tighten.

**STEP 5:** In the same corner which you have installed the vertical 2 x 4, insert a horizontal 2 x 4 support and butt it to the vertical 2 x 4. Insert one (1) screw into the predrilled hole on the side of the End Bracket and tighten to the horizontal support.

**STEP 6:** Repeat STEP 5 on the opposite side of the End Bracket you are working on, and then repeat STEP 4 and 5 on both corners of the other End Bracket.

