

American Standard

INSTALLATION INSTRUCTIONS


7353.801

7353.841

TOWNSEND® DUAL CONTROL WIDESPREAD LAVATORY FAUCET

*Thank you for selecting American Standard...
the benchmark of fine quality for over 140 years.*

**To ensure that your installation proceeds smoothly-please
read these instructions carefully before you begin.**



Certified to comply with ANSI A112.18.1M

RECOMMENDED TOOLS




Flat Head Screwdriver



Slip Jaw Pliers



Adjustable Wrench




Tubing Cutter

1 INSTALL SPOUT

CAUTION Turn off hot and cold water
supplies before beginning.

Fig. A.


- Insert SHANK (1) and HOSE (2) through center hole, making sure SEAL WASHER (3) is properly seated in spout base.
- From below, push RETAINING WASHER (4) onto SHANK (1). Secure faucet with MOUNTING NUT (5).
- Align and center SPOUT. Tighten MOUNTING NUT (5).
- Push the TEE ASSEMBLY (9) into the HOSE CONNECTOR (10) slide down LOCKING COLLAR (11) until it snaps into place to secure connection.




1A INSTALL VALVE BODIES

Fig. B.

- Remove LOCKNUT (6) from SIDE VALVE SHANKS (7).
- Insert Hot and Cold SIDE VALVE HOSES (8), FLEXIBLE SUPPLIES (8a) into mounting holes.
- Thread LOCKNUT (6) onto each SIDE VALVE SHANK (7) from underside of sink or mounting surface.
- Align and center SIDE VALVES. Tighten LOCKNUTS (6).




2 INSTALL DRAIN FROM BELOW FIXTURE



- Install DRAIN (1) by dropping it from the top of the sink.
- From under side of SINK install GASKET (2) and MOUNTING NUT (3).


Note: Plumber's putty or caulk is recommended.

3




- Thread TAIL PIECE NUT (1) clockwise onto DRAIN BODY (2).

4 FLANGE GASKET AND POP-UP KNOB



- Check DRAIN FLANGE in SINK to ensure that FOAM GASKET is fully compressed and not visible.

5 CHECK OPERATION OF POP-UP



- Operate DRAIN STOPPER (1) to verify that it opens and closes.


6 MAKE WATER SUPPLY AND WASTE CONNECTIONS

- Connect FLEXIBLE SUPPLIES (1, 2) directly to wall supplies. Connection on fitting supplies are 3/8" compression. Connect FLEXIBLE SUPPLY (1) (Marked with a Red Band) to the Left wall supply and FLEXIBLE SUPPLY (2) (Marked with a Blue Band) to Right wall supply.
- Connect the VALVE HOSES (3, 3a) to SPOUT TEE (4), and secure it with the sleeve by sliding it over.
- Faucet supplies are 20" long from faucet base.

Note: If additional supply length is required, installer must purchase additional parts separately.

Important: If SUPPLY HOSES (1, 2) are to long, loop as illustrated to avoid kinking.

- Connect 1-1/4" O.D. tail piece on POP-UP DRAIN to waste outlet.



7 SERVICE

Change Direction of the Handle


- Turn valves to OFF position.
- Turn off water supplies.
- Pull HANDLE (1) "UP" firmly to release from ESCUTCHEON (6).
- Remove SCREW (3) and pull off PLASTIC INSERT (2).
- Remove CARTRIDGE NUT (8).
- Remove RETAINING O-RING (4).
- Lift and turn STOP WASHER (5) 90°. Replace RETAINING O-RING (4).
- Re-install HANDLE ASSEMBLY.

To Change Cartridge:

- Remove HANDLE (1), ADAPTER (2), SCREW (3) and CARTRIDGE NUT (8) via steps above.
- Remove cartridge by pulling upward on stem.

Aerator Clean Out

- AERATOR may accumulate dirt causing distorted and reduced water flow. Remove AERATOR by using the edge of a coin and rinse to clear any debris.
- If spout drips, operate handles several times from OFF to ON position. Do not force - handles turn only 90°.



8

CARE INSTRUCTIONS:

DO: SIMPLY RINSE THE PRODUCT CLEAN WITH CLEAR WATER. DRY WITH A SOFT COTTON FLANNEL CLOTH.

DO NOT: DO NOT CLEAN THE PRODUCT WITH SOAPS, ACID, POLISH, ABRASIVES, HARSH CLEANERS, OR A CLOTH WITH A COARSE SURFACE.