

SEWER AND DRAIN MAINTENANCE CABLE AND ACCESSORY MATRIX

	LINE SIZE	CABLE DIAMETER	MODEL #	DESCRIPTION	COMPATIBLE WITH	HEAD ATTACHMENTS w/ RUST GUARD™ PLATING			
AUGER CABLES	1-1/4" – 2"	3/8"	48-53-2577	3/8" x 6' Bulb Head TRAPSSNAKE™ Urinal	TRAPSSNAKE™ 4' Urinal Auger 2574, 49-16-2574	N/A			
	2" – 4"	1/2"	48-53-2576	1/2" x 4' Bulb Head TRAPSSNAKE™ Toilet	TRAPSSNAKE™ 6' Toilet Auger 2576, 49-16-2576	N/A			
	1/2" – 2"	1/4"	48-53-2578	1/4" x 25' Drop Head Cable	TRAPSSNAKE™ 25' Auger w/ CABLE DRIVE™ 49-16-2573	N/A			
	1/2" – 2"	1/4"	48-53-2579	1/4" x 25' Bulb Head Cable	TRAPSSNAKE™ 25' Auger w/ CABLE DRIVE™ 49-16-2573	N/A			
HANDHELD MACHINE CABLES	1-1/4" – 2"	1/4"	48-53-2563	1/4" x 25' Inner Core Bulb Head w/ RUST GUARD™	M12™ Drain Snake – 2571 M18 FUEL™ Drain Snake w/ CABLE DRIVE™ – 2772	N/A			
			48-53-2564	1/4" x 25' Inner Core Drop Head w/ RUST GUARD™					
			48-53-2671	1/4" x 35' Inner Core Bulb Head w/ RUST GUARD™					
			48-53-2672	1/4" x 50' Inner Core Bulb Head w/ RUST GUARD™					
	1-1/4" – 2-1/2"	5/16"	48-53-2561	5/16" x 25' Inner Core Bulb Head w/ RUST GUARD™	M12™ Drain Snake – 2571 M18 FUEL™ Drain Snake w/ CABLE DRIVE™ – 2772	N/A			
			48-53-2562	5/16" x 25' Inner Core Drop Head w/ RUST GUARD™					
			48-53-2673	5/16" x 35' Inner Core Bulb Head w/ RUST GUARD™					
			48-53-2674	5/16" x 50' Inner Core Bulb Head w/ RUST GUARD™					
	2" – 3"	3/8"	48-53-2676	3/8" x 25' Inner Core w/ RUST GUARD™	M18 FUEL™ Drain Snake w/ CABLE DRIVE™ 2772	48-53-2685	2" – 3" Head Attachment Kit	48-53-2681	Small Bulb Head
			48-53-2675	3/8" x 35' Inner Core w/ RUST GUARD™				48-53-2682	Small Drop Head
								48-53-2683	1" Spade Bit
								48-53-2684	1" C-Cutter
DRUM MACHINE CABLES	1-1/4" – 2"	5/16"	48-53-2772	5/16" x 75' Inner Core Drop Head w/ RUST GUARD™	M18 FUEL™ SWITCH PACK™ Sectional Drum Machine 2775	N/A			
	1-1/4" – 3"	5/8"	48-53-2775	5/8" x 50' Flexible Open Wind w/ RUST GUARD™	M18 FUEL™ SWITCH PACK™ Sectional Drum Machine 2775	48-53-2685	2" – 3" Head Attachment Kit	48-53-2681	Small Bulb Head
								48-53-2682	Small Drop Head
								48-53-2683	1" Spade Bit
								48-53-2684	1" C-Cutter
	1-1/2" – 3"	3/8"	48-53-2776	3/8" x 75' Inner Core Cable	M18™ Drum Machine 2817	48-53-2790	3" – 4" Head Attachment Kit	48-53-2786	Medium Funnel Head
	1-1/2" – 3"	3/8"	48-53-2777	3/8" x 100' Inner Core Cable				48-53-2787	Medium Drop Head
								48-53-2788	1-1/2" Spade Bit
								48-53-2789	1-1/2" C-Cutter
	2" – 3"	3/8"	48-53-2773	3/8" x 50' Inner Core w/ RUST GUARD™	M18 FUEL™ SWITCH PACK™ Sectional Drum Machine 2775	48-53-2790	3" – 4" Head Attachment Kit	48-53-2786	Medium Funnel Head
								48-53-2787	Medium Drop Head
								48-53-2788	1-1/2" Spade Bit
								48-53-2789	1-1/2" C-Cutter
	3" – 4"	1/2"	48-53-2774	1/2" x 25' Inner Core w/ RUST GUARD™	M18 FUEL™ SWITCH PACK™ Sectional Drum Machine 2775	48-53-2790	3" – 4" Head Attachment Kit	48-53-2786	Medium Funnel Head
								48-53-2787	Medium Drop Head
								48-53-2788	1-1/2" Spade Bit
48-53-2789								1-1/2" C-Cutter	
3" – 4"	1/2"	48-53-2778	1/2" x 75' Inner Core Cable	M18™ Drum Machine 2817	48-53-2790	3" – 4" Head Attachment Kit	48-53-2786	Medium Funnel Head	
							48-53-2787	Medium Drop Head	
							48-53-2788	1-1/2" Spade Bit	
							48-53-2789	1-1/2" C-Cutter	
3" – 6"	5/8"	48-53-2325	5/8" x 25' Inner Core	MX FUEL™ Sewer Drum Machine MXF500	48-53-2840	3" – 8" Head Attachment Kit	48-53-2830	Straight Auger	
							48-53-2831	Funnel Auger	
							48-53-2832	3" Root Cutter	
		48-53-2350	5/8" x 50' Inner Core				48-53-2833	4" Root Cutter	
							48-53-2834	6" Root Cutter	
							48-53-2835	3" Opening Tool	
48-53-2310	5/8" x 100' Inner Core	48-53-2836	4" Opening Tool						
		48-53-2837	3" Grease Cutter						
							48-53-2838	4" Grease Cutter	

SEWER AND DRAIN MAINTENANCE CABLE AND ACCESSORY MATRIX

	LINE SIZE	CABLE DIAMETER	MODEL #	DESCRIPTION	COMPATIBLE WITH	HEAD ATTACHMENTS w/ RUST GUARD™ PLATING			
DRUM MACHINE CABLES CONT'D	4" – 8"	3/4"	48-53-2425	3/4" x 25' Inner Core	MX FUEL™ Sewer Drum Machine MXF500 MX FUEL™ Sewer Drum Machine w/ POWERTREDZ™ MXF501	48-53-2840	3" – 8" Head Attachment Kit	48-53-2830	Straight Auger
								48-53-2831	Funnel Auger
								48-53-2832	3" Root Cutter
			48-53-2833	4" Root Cutter					
			48-53-2834	6" Root Cutter					
			48-53-2835	3" Opening Tool					
			48-53-2836	4" Opening Tool					
			48-53-2837	3" Grease Cutter					
			48-53-2838	4" Grease Cutter					
SECTIONAL MACHINE CABLES	1-1/4" – 2"	5/8"	48-53-2680	5/8" x 7-1/2' All-Purpose	M18 FUEL™ Sectional Machine 2818	48-53-3820	1-1/4" – 2" Head Attachment Kit	48-53-3811	Drop Head Bulb Auger
								48-53-3812	Drop Head Straight Auger
								48-53-3813	Funnel Auger
								48-53-3814	Opening Tool
								48-53-3815	1-1/2" Opening Tool
	2" – 6"	7/8"	48-53-2852	7/8" x 15' All-Purpose	M18 FUEL™ Sectional Machine 2818 M18 FUEL™ Sewer Sectional Machine w/ CABLE DRIVE™ 2871	48-53-3839	2" – 4" Head Attachment Kit	48-53-3829	Flexible Straight Auger
								48-53-3828	Flexible Funnel Auger
								48-53-3827	2" Opening Tool
								48-53-3835	3" Opening Tool
								48-53-3825	2" Root Cutter
						48-53-3832	3" Root Cutter		
						48-53-3837	3" Grease Cutter		
						48-53-3840	3" – 6" Head Attachment Kit	48-53-3830	Straight Auger
								48-53-3831	Funnel Auger
								48-53-3832	3" Root Cutter
	48-53-3833	4" Root Cutter							
	48-53-3834	6" Root Cutter							
	48-53-3835	3" Opening Tool							
	48-53-3836	4" Opening Tool							
	48-53-3837	3" Grease Cutter							
	48-53-3838	4" Grease Cutter							
3" – 8"	1-1/4"	48-53-2851	1-1/4" x 15' All-Purpose	M18 FUEL™ Sewer Sectional Machine w/ CABLE DRIVE™ 2871	48-53-4840	3" – 8" Head Attachment Kit	48-53-4830	Straight Auger	
		48-53-2854	1-1/4" x 15' Heavy Duty				48-53-4831	Funnel Auger	
							48-53-4832	3" Root Cutter	
							48-53-4833	4" Root Cutter	
							48-53-4834	6" Root Cutter	
							48-53-4835	3" Opening Tool	
							48-53-4836	4" Opening Tool	
							48-53-4837	3" Grease Cutter	
							48-53-4838	4" Grease Cutter	