

# HEAD ATTACHMENTS

Drop Head Straight Auger



**Used for All-Purpose Cleaning and to Retrieve Parts of the Blockages**

Drop Head Bulb Auger



**All-Purpose Cleaning and Retrieval of Lost Objects**

Funnel Head



**Retrieval of Lost Objects and Broken Cables**

Straight Auger



**Used to Retrieve Part of the Blockage**

Funnel Auger



**Retrieval of Lost Objects and Broken Cables**

Spade Bit



**Breaks Up and Clears Solid Blockages**

C-Cutter



**Scrapes Grease and Sludge From Pipe Walls**

Opening Tool



**Breaks Up Solid Blockages and Scales Down Build Up**

Grease Cutter



**Breaks Up Grease**

Root Cutter



**Cuts Through Roots**

Pin Key



**Release Interlocking Cable Connectors and Cable Head Attachments**

Head Attachment Case  
48-53-2839



**Store Cable Head Attachments**

	LINE SIZE	CABLE DIAMETER	MODEL #	DESCRIPTION	COMPATIBLE WITH	HEAD ATTACHMENTS w/ RUST GUARD™ PLATING				
AUGER CABLES	1-1/4" – 2"	3/8"	48-53-2577	3/8" x 6' Bulb Head TRAPSNAKE™ Urinal	TRAPSNAKE™ 4' Urinal Auger 2574, 49-16-2574	N/A				
	2" – 4"	1/2"	48-53-2576	1/2" x 4' Bulb Head TRAPSNAKE™ Toilet	TRAPSNAKE™ 6' Toilet Auger 2576, 49-16-2576	N/A				
HANDHELD MACHINE CABLES	1-1/4" – 2"	1/4"	48-53-2563	1/4" x 25' Inner Core Bulb Head w/ RUST GUARD™	M12™ Drain Snake – 2571 M18 FUEL™ Drain Snake w/ CABLE DRIVE™ – 2772	N/A				
			48-53-2564	1/4" x 25' Inner Core Drop Head w/ RUST GUARD™		N/A				
			48-53-2671	1/4" x 35' Inner Core Bulb Head w/ RUST GUARD™		N/A				
			48-53-2672	1/4" x 50' Inner Core Bulb Head w/ RUST GUARD™		N/A				
	1-1/4" – 2-1/2"	5/16"	48-53-2561	5/16" x 25' Inner Core Bulb Head w/ RUST GUARD™	M12™ Drain Snake – 2571 M18 FUEL™ Drain Snake w/ CABLE DRIVE™ – 2772	N/A				
			48-53-2562	5/16" x 25' Inner Core Drop Head w/ RUST GUARD™		N/A				
			48-53-2673	5/16" x 35' Inner Core Bulb Head w/ RUST GUARD™		N/A				
			48-53-2674	5/16" x 50' Inner Core Bulb Head w/ RUST GUARD™		N/A				
2" – 3"	3/8"	48-53-2676	3/8" x 25' Inner Core w/ RUST GUARD™	M18 FUEL™ Drain Snake w/ CABLE DRIVE™ 2772	48-53-2685	2" – 3" Head Attachment Kit	48-53-2681	Small Bulb Head		
		48-53-2675	3/8" x 35' Inner Core w/ RUST GUARD™				48-53-2682	Small Drop Head		
DRUM MACHINE CABLES	1-1/4" – 2"	5/16"	48-53-2772	5/16" x 75' Inner Core Drop Head w/ RUST GUARD™	M18 FUEL™ SWITCH PACK™ Sectional Drum Machine 2775	N/A				
	1-1/4" – 3"	5/8"	48-53-2775	5/8" x 50' Flexible Open Wind w/ RUST GUARD™	M18 FUEL™ SWITCH PACK™ Sectional Drum Machine 2775	48-53-2685	2" – 3" Head Attachment Kit	48-53-2681	Small Bulb Head	
	2" – 3"	3/8"	48-53-2773	3/8" x 50' Inner Core w/ RUST GUARD™	M18 FUEL™ SWITCH PACK™ Sectional Drum Machine 2775			48-53-2682	Small Drop Head	
						48-53-2786	Medium Funnel Head			
	3" – 4"	1/2"	48-53-2774	1/2" x 25' Inner Core w/ RUST GUARD™	M18 FUEL™ SWITCH PACK™ Sectional Drum Machine 2775	48-53-2790	3" – 4" Head Attachment Kit	48-53-2683	1" Spade Bit	
								48-53-2789	1" C-Cutter	
	3" – 6"	5/8"	48-53-2325	5/8" x 25' Inner Core	MX FUEL™ Sewer Drum Machine MXF500	48-53-2840	3" – 8" Head Attachment Kit	48-53-2786	Medium Funnel Head	
			48-53-2350	5/8" x 50' Inner Core				48-53-2787	Medium Drop Head	
			48-53-2310	5/8" x 100' Inner Core				48-53-2788	1-1/2" Spade Bit	
			48-53-2425	3/4" x 25' Inner Core				MX FUEL™ Sewer Drum Machine MXF500	48-53-2789	Medium Funnel Head
									48-53-2450	3/4" x 50' Inner Core
			48-53-2410	3/4" x 100' Inner Core				MX FUEL™ Sewer Drum Machine w/ POWERREDZ™ MXF501	48-53-2788	1-1/2" Spade Bit
SECTIONAL MACHINE CABLES	1-1/4" – 2"	5/8"	48-53-2680	5/8" x 7-1/2' All-Purpose	M18 FUEL™ Sectional Machine 2818	48-53-3820	1-1/4" – 2" Head Attachment Kit	48-53-2830	Straight Auger	
	2" – 6"	7/8"	48-53-2852	7/8" x 15' All-Purpose	M18 FUEL™ Sewer Sectional Machine w/ CABLE DRIVE™ 2871			48-53-2831	Funnel Auger	
						48-53-2832	3" Root Cutter			
						48-53-3811	Drop Head Bulb Auger			
						48-53-3812	Drop Head Straight Auger			
						48-53-3813	Funnel Auger			
						48-53-3814	Opening Tool			
	3" – 8"	1-1/4"	48-53-2854	1-1/4" x 15' Heavy Duty	M18 FUEL™ Sewer Sectional Machine w/ CABLE DRIVE™ 2871	48-53-3815	1-1/2" Opening Tool			
						48-53-3829	Flexible Straight Auger			
						48-53-3828	Flexible Funnel Auger			
						48-53-3827	2" Opening Tool			
						48-53-3835	3" Opening Tool			
48-53-3825						2" Root Cutter				
48-53-3839	2" – 4" Head Attachment Kit	48-53-3832	3" Root Cutter							
		48-53-3837	3" Grease Cutter							
		48-53-3830	Straight Auger							
		48-53-3831	Funnel Auger							
		48-53-3832	3" Root Cutter							
		48-53-3833	4" Root Cutter							
		48-53-3834	6" Root Cutter							
		48-53-3835	3" Opening Tool							
		48-53-3836	4" Opening Tool							
		48-53-3837	3" Grease Cutter							
		48-53-3838	4" Grease Cutter							
		48-53-3840	3" – 6" Head Attachment Kit	48-53-3837	3" Grease Cutter					
48-53-3830	Straight Auger									
48-53-3831	Funnel Auger									
48-53-3832	3" Root Cutter									
48-53-3833	4" Root Cutter									
48-53-3834	6" Root Cutter									
48-53-3835	3" Opening Tool									
48-53-3836	4" Opening Tool									
48-53-3837	3" Grease Cutter									
48-53-3838	4" Grease Cutter									
48-53-4840	3" – 8" Head Attachment Kit			48-53-4830	Straight Auger					
				48-53-4831	Funnel Auger					
		48-53-4832	3" Root Cutter							
		48-53-4833	4" Root Cutter							
		48-53-4834	6" Root Cutter							
		48-53-4835	3" Opening Tool							
		48-53-4836	4" Opening Tool							
		48-53-4837	3" Grease Cutter							
		48-53-4838	4" Grease Cutter							