

Outdoor Foot Pedal Accessory Compatibility Guide

Hands-free Activation

Foot pedal easily attaches to the bottom panel of the ezH2O® outdoor tubular bottle filling station to provide the option for hands-free bottle filling activation. Available in 12 coordinating bottle filling station colors and Pantone® colors based on minimum order quantity. Sold separately, not factory assembled.



Compatible Models	Description
LK4400BF	Pedestal, Non-filtered Non-refrigerated
LK4420BF1U	Bi-level Pedestal, Non-filtered Non-refrigerated
LK4420BF1UDB	Bi-level Pedestal With Pet Station, Non-filtered, Non-refrigerated

*Compatible units shown with foot pedal 4481FP installed.

Visit elkay.com/outdoor for more information.