



**LP67288** Sku: 46641  
**Lawn and Garden Set**  
 Pack: 4 – Age grade: 2+  
 3-piece value set. Pull string on trimmer to spin grass clippings, no batteries required.

Role Play



**TBEK35060**  
**Real Sounds Lawn Mower**  
 Pack: 4 – Age grade: 2+  
 Interactive John Deere lawn mower with rotating grass clippings. Press button for sound and music. Includes (3) "AA" batteries.



**TBEK35083**  
**Roll N Go Flashlight**  
 Pack: 6 – Age grade: 18 mos.+  
 Squeeze cab to start tractor engine, flip open hood, and turn on light. Free rolling wheels for push along fun. Includes (2) "AA" batteries.