


NEVER LEAVE THE HEATER UNATTENDED WHILE BURNING!

Model # MH170QFAVT (WITH THERMOSTAT) PARTS LIST



Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	27459	Guard, rear, assembly	1	27	40959	Fitting brass connector 1/4NPT	1
2	21551	Motor assembly	1	28	20126	Solenoid valve, Goyen	1
3	27898	Fan assembly	1	29	40958	Fitting brass connector 5/8-18	1
4	27460	Flame holder	1	30	21036	Power Cord	1
5	27461	Burner, mesh, assembly	1	31	26223	Bushing Strain Relief	1
6	N/A	Ignition Electrode	1	32	27005	Motor Supporting Bracket 1	1
7	27462	High limit control assembly	1	33	27006	Motor Supporting Bracket 2	1
8	27925	Carry Handle	2	*	26152	Hose assembly	1
9	40715	High limit control	1	*	27493	Hose 10', w/Regulator Assembly	1
10	27474	Radiation shield	1				
11	27023	Barrel assembly	1				
12	27476	Burner gas tubing	1				
13	27808	Potted flame control	1				
14	28771	Terminal block	1				
15	26070	Loop clamp 5/16"	1				
16	22254	Thermostat assembly	1				
17	25026	Elevation knob	1				
18	27477	Elevation plate	1				
19	27478	Metal base assembly	1				
20	27479	Metal base bottom panel	1				
21	28772	Thermostat knob	1				
22	28773	Variable valve knob	1				
23	40900	Orifice holder assembly	1				
24	27480	Orifice	1				
25	N/A	Solenoid valve bracket	1				
26	40877	Variable valve assembly	1				

* Item not shown on exploded view