

PRISTIVE™

TANKLESS REVERSE OSMOSIS SYSTEM

User Guide

BRIZO®

Purer water *beckons*.

Water's most perfect state. The Pristine™ Tankless Reverse Osmosis System reduces more than 90 contaminants from your drinking water, when tested against NSF standards. The result is the truest essence of water: naturally refreshing and free of worry from impurities.



INSTALLATION TUTORIAL

<https://www.youtube.com/brizo>

PRISTIVE™ REVERSE OSMOSIS SYSTEM


■ INCLUDED IN THE BOX

■ NOT INCLUDED IN THE BOX


- RO faucet with air gap
- RO faucet with air gap waste line
- Cold water supply stop
- Standard faucet



CARTRIDGES MAY ROTATE DURING SHIPPING.



Confirm correct orientation before use.



RO Unit front cover not pictured

REPLACING PRISTIVE™ FILTERS



Carbon Filter Cartridge

Filter Life: 2 years or
1,320 gallons



Reverse Osmosis Filter Cartridge

Filter Life: 2 years or
1,320 gallons

HOW TO REPLACE CARBON FILTER CARTIDGE AND RO FILTER CARTRIDGE

- Rotate the handle counterclockwise to unlock and pull cartridge out
- Insert new cartridges with the handle oriented vertically
- Rotate cartridge clockwise to lock in place
- Handle should be horizontal and flush with the front panel when fully installed
- Manually reset each filter life by pressing the icon under its indicator light for 5 seconds
- Repeat for each filter
- System will beep once to signal successful reset
- After replacing both cartridges, turn on faucet and manually flush the system for 30 mins to break in new filters

HOW TO REPLACE PRE-FILTER

- Turn off water supply from tee fitting
- Turn on RO faucet
- Unplug power cord while faucet is on
- Turn off faucet
- Disconnect pre-filter by compressing fitting flange while pulling tubing straight out
- Insert new pre-filter using push-to-connect fittings
- Turn on water supply line, plug in power cord and inspect for leaks
- Record installation date for future reference to help maintain replacement schedule

Refer to the installation instructions for additional details on replacement, if needed.

LOCATE YOUR
REPLACEMENT
FILTER



www.brizo.com/kitchen/filters



Pre-Filter

Filter Life: 6 years or
3,960 gallons

INDICATORS



Water Indicator

The indicator light will be blue while filtering water. It will turn off when water is not being dispensed.



Filter Life Indicator

● **Solid Blue:** Filter life is normal.



● **Solid Purple:** Filter life will expire soon.*

● **Solid Red:** Filter life has expired.*



Filtered Outlet Water Quality Indicator

● **Solid Blue:** Low amount of TDS

● **Solid Purple:** Medium amount of TDS

● **Solid Red:** High amount of TDS

If an indicator is blinking or flashing, consult the user manual.

Sound

The unit will **beep twice** per use when the filter is nearing end of life.* It will **beep constantly** during use once the filter is exhausted.

*We recommend to order replacements at this time.

TRACK YOUR FILTER MAINTENANCE

Filter Name	Date Changed	Filter Name	Date Changed



Optional Remineralizer Cartridge

(PURCHASED SEPARATELY)

Reduce impurities *and* maintain naturally refreshing taste. While the Pristine™ Tankless Reverse Osmosis System reduces impurities from your drinking water, it also removes naturally occurring minerals that give your water its crisp taste. The Remineralizer Cartridge ensures those minerals, like calcium and magnesium, are delivered back to your filtered drinking water for elevated taste and pH.



REGISTER YOUR SYSTEM HERE:

<https://www.brizo.com/customer-support/product-registration>

For live customer support: 877-345-2749

BRIZO®

115977 Rev A 04/24