





Happy D.2 One-Piece Toilet Spare Parts

212101..01 # 212151..01

Description		Model No.	USD
	Tank lid	212199 00 00	130
	Push button (Dual Flush) 132 mm, 5 1/4 in	007596 10 00	5
	Flush valve (with push button)	007419 07 00	25
	Flush valve gasket	007412 75 00	5
	Fill valve	007411 82 00	35
	Fill valve repair kit	100457 00 00	10
	Connection set for SensoWash seats with concealed connections	100681 00 00*	150
	Connection set for SensoWash seats with concealed connections (replacement for 100681 00 00)	100700 00 00	150

* Discontinued while supplies last

**DuraStyle Two-Piece Toilet Spare Parts**# 216001..00 # 093520..05
216051..00

Description	Model No.	USD
 Push button (Dual Flush) 132 mm, 5 1/4 in	007596 10 00	5
 Flush valve 3"	007419 05 00	100
 Flush valve gasket	007412 75 00	5
 Fill valve	007411 81 00	20
Fill valve repair kit	100457 00 00	10
 Tank to bowl gasket & hardware	007412 71 00	25
 Connection set for SensoWash seats with concealed connections	100681 00 00*	150

* Discontinued while supplies last

**DuraStyle Two-Piece Toilet Spare Parts**# 216001..85 # 093520..85
216051..85

Description	Model No.	USD
 Push button, single flush (80 mm, 3 1/8 in)	007509 10 00	25
 Flush valve, single flush	007413 86 00	100
 Flush valve gasket	100297 00 00	10
 Fill valve	007411 22 00	90
Fill valve repair kit	100457 00 00	10
 Tank to bowl gasket & hardware	007412 71 00	25
 Connection set for SensoWash seats with concealed connections	100681 00 00*	150
 Connection set for SensoWash seats with concealed connections (replacement for 100681 00 00)	100700 00 00	150

* Discontinued while supplies last



Happy D.2 Two-Piece Toilet Spare Parts

011201..XX # 092910..05

	Description	Model No.	USD
	Push button, single flush	007509 10 00	25
	Flush valve, single flush	007413 76 00	105
	Flush valve gasket	100297 00 00	10
	Fill valve	007411 22 00	90
	Fill valve repair kit	100457 00 00	10
	Tank to bowl gasket & hardware	007412 71 00	25



Happy D.2 Two-Piece Toilet Duravit Rimless® Spare Parts

217401* # 093420..01*
217451*

	Description	Model No.	USD
	Fill valve	007411 83 00	15
	Flush Valve, push button and hardware included	007419 10 00	25
	Fill valve repair kit	100457 00 00	10
	Flush valve gasket	007412 75 00	5
	Push button (Dual Flush) 132 mm, 5 1/4 in	007596 10 00	5
	Tank to bowl gasket & hardware	007412 71 00	25

* Discontinued