


## 50033847-001 SuitePRO™ Adaptor Plate

### INSTALLATION INSTRUCTIONS



### PRODUCT DESCRIPTION

The 50033847-001 Adaptor Plate is used to attach a SuitePRO™ thermostat to a 4 x 4 in. junction box or to a 2 x 4 in. junction box in the vertical position. Mounting screws are supplied.

The adaptor plate may be used on all SuitePRO™ thermostat models: TB6575A1000, TB6575B1000, and TB8575A1000.

NOTE: The adaptor plate is not needed when mounting a SuitePRO™ thermostat horizontally on a 2 x 4 in. junction box.

### SPECIFICATIONS

**Dimensions:** Length 6 1/4 in. (158 mm), Width 5 1/16 in. (128 mm), Depth 13/32 in. (10 mm)

**Construction:** Plastic

SuitePRO™ is a trademark of Honeywell International Inc.

#### Automation and Control Solutions

Honeywell International Inc.  
1985 Douglas Drive North  
Golden Valley, MN 55422  
customer.honeywell.com

Honeywell Limited-Honeywell Limitée  
35 Dynamic Drive  
Toronto, Ontario M1V 4Z9

© U.S. Registered Trademark  
© 2008 Honeywell International Inc.  
62-0286ES—01 M.S. 07-08



Printed in U.S.A. on recycled paper containing at least 10% post-consumer paper fibers.

### INSTALLATION

#### Location

The thermostats are the temperature control element in a fan coil or air-conditioning system. They must be located about 1.5m (5 ft.) above the floor in a position with good air circulation to sense room temperature.

#### Mounting

The thermostat must be mounted flush to the wall. Mounting screws are supplied.

For the mounting steps, refer to Fig. 1:

1. Feed the supply wires through the junction box and the opening in the adaptor plate.
2. Affix the adaptor plate to the junction box using the screws provided.
3. Refer to the *TB6575/TB8575 SuitePRO™ Digital Fan Coil Thermostats – Installation Guide* (form 62-0278) for installation of the thermostat.
4. Insert the adaptor plate's screw head cover.




Fig. 1. Mounting the adaptor plate (50033847-001).

