




Model XCS01Z Parts List

A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	187142-8	HOUSING SET	1 SET
002	266130-9	TAPPING SCREW BIND PT 3X16	10 PC.
003	419642-3	REAR COVER	1 PC.
004	263032-0	RUBBER PIN 4	2 PC.
005	195021-6	CARBON BRUSH CB-440	1 SET
006	638849-4	BRUSH HOLDER COMPLETE	1 PC.
007	451163-9	COVER	1 PC.
008	687216-0	LENS CASE	1 PC.
009	451162-1	LOCK LEVER	1 PC.
010	689145-3	HEATSINK	1 PC.
011	911006-2	PAN HEAD SCREW M3X8	1 PC.
012	650653-1	SWITCH TG553FSB-4B	1 PC.
013	644808-8	TERMINAL	1 PC.
014	619165-3	ARMATURE	1 PC.
015	638425-4	YOKE UNIT	1 PC.
016	450386-6	MOTOR BRACKET	1 PC.
017	227129-9	INTERNAL GEAR 46	1 PC.
018	267789-5	FLAT WASHER 18	1 PC.
019	154468-3	SPUR GEAR 16 COMPLETE	3 PC.
020	141744-4	CARRIER COMPLETE	1 PC.
021	419252-6	GEAR CASE	1 PC.
022	911017-7	PAN HEAD SCREW M3X12	4 PC.
023	961055-9	RETAINING RING S-15	1 PC.
024	211234-2	BALLBEARING 6902LLB	1 PC.
025	318455-8	GEAR CASE B	1 PC.
026	266045-0	TAPPING SCREW 4X20	4 PC.
027	211233-4	BALL BEARING 6802LLB	1 PC.
028	326213-8	SPINDLE	1 PC.
030	SC00000061	HEX. BOLT 10X15	1 PC.
031	SC00000489	SEAL WASHER WF10171.6	1 PC.
032	SC03213510	PUMP CASE	1 PC.
033	SC00000054	OIL SEAL	1 PC.
034	SC00000050	BALL BEARING 6002RU	1 PC.
035	SC03501390	ECCENTRIC SHAFT	1 PC.
036	SC03251400	THRUST FIXING FLANGE	1 PC.
037	SC03221700	MOTOR FLANGE	1 PC.
038	SC00000066	WASHER 6	4 PC.
039	922382-9	HEX. SOCKET HEAD BOLT M6X60	4 PC.
040	SC07511020	BOLT HB4X15	4 PC.
041	SC00000068	WASHER 4	4 PC.
042	SC03222300	MOTOR MOUNTING FLANGE	1 PC.
043	SC00000068	WASHER 4	4 PC.
044	SC07511020	BOLT HB4X15	4 PC.
045	SC04007620	LEAF SPRING	2 PC.
046	SC04007430	POSITION SPRING	2 PC.
047	SC07900010	STEEL BALL S4	2 PC.
048	SC04601470	LINER B	1 PC.
049	SC07411020	RETAINING RING RTW-26	1 PC.
050	SC00000019	NEEDLE BEARING SUPPORTER	2 PC.

051	SC00000048	NEEDLE BEARING	1 PC.
052	SC00000049	BALL BEARING 608	1 PC.
053	SC00000020	MAGNET	3 PC.
054	941201-0	FLAT WASHER 8	3 PC.
055	SC00000376	HEX. SOCKET HEAD BOLT 8X20	3 PC.
056	SC06505300	O RING S4	1 PC.
057	SC03501420	RETURN BULB	1 PC.
058	SC00000015	PISTON	3 PC.
059	SC00000022	PISTON RETURN SPRING	3 PC.
060	SC00000464	CHECK VALVE #T43445N1	3 PC.
061	SC00000021	CHECK VALVE SPRING	3 PC.
062	SC03500540	METAL PACKING	3 PC.
063	SC06505590	O RING S-8	3 PC.
064-1	SC03206140	CYLINDER	1 PC.
	D10	INC. 52,58	
065	SC06505010	O RING P6	2 PC.
066	SC06503260	BACK UP RING G70	1 PC.
067	SC06505350	O RING FOR CYLINDER G70	1 PC.
068	SC00000023	RELEASE VALVE SPRING	1 PC.
069	SC00000060	HEX. SOCKET HEAD BOLT 4X6	2 PC.
070	SC00000481	STOPPER PLATE #45423	1 PC.
071	SC00000032	VALVE RETURN SPRING	1 PC.
072	SC03500310	RELEASE VALVE	1 PC.
073	SC00000096	ROD PACKING	1 PC.
074	SC03112300	CUTTER ROD	1 PC.
075	SC03700020	KEY	1 PC.
076	SC00000070	SPRING PIN 2.5X10	1 PC.
077	SC09002030	SP BLADE SET (PC)	1 PC.
078	SC00000067	WASHER 5	2 PC.
079	SC00000098	HEX. SOCKET HEAD BOLT 5X15	2 PC.
080	SC04000050	RETURN SPRING FOR CUTTER ROD	1 PC.
081	SC06503510	DUST SEAL	1 PC.
082	SC07620040	WASHER HW8	11 PC.
083	922441-9	HEX. SOCKET HEAD BOLT M8X25	11 PC.
084	SC00000057	HEX. SOCKET HEAD BOLT 6X18	2 PC.
085	SC00000066	WASHER 6	2 PC.
086	931601-2	HEX. NUT M12	1 PC.
087	SC00000134	HOLD BOLT	1 PC.
088	SC00000034	WOOD SCREW 5X60	1 PC.
089	SC00000065	SPRING WASHER 8	1 PC.
090	SC03507010	BUSHING HOLDER	1 PC.
091	SC06505320	O RING P26	1 PC.
092	SC03507000	BUSHING	1 PC.
093	SC09004910	OIL LEVELER SACK	1 PC.
095	SC03302640	HANDGRIP	1 PC.
096	SC09030630	SCREW SET	1 PC.
097	SC07513030	BOLT HB6X18	1 PC.
098	SC07610040	WASHER SW6	2 PC.
099	SC03302650	SPACER	1 PC.
100	SC03223430	HANDGRIP RING	1 PC.
101	SC07513090	HEX. SOCKET HEAD BOLT M6X22	1 PC.
104	SC03505790	PROTECTOR	1 PC.
105	SC07610030	WASHER SW5	1 PC.
106	SC07512010	BOLT HB5X5	1 PC.
108	SC03103210	BAR HOLDER	1 PC.
A03	783201-2	HEX. WRENCH 3	1 PC.

A04	783202-0	HEX. WRENCH 4	1 PC.
A05	783203-8	HEX. WRENCH 5	1 PC.
A06	783204-6	HEX. WRENCH 6	1 PC.
A07	781212-1	WRENCH 17-19	1 PC.
A08	SC00000142	OIL 150CC	1 PC.
A09	SC09009190	PLASTIC CASE SET	1 PC.