


**PARTS IDENTIFICATION DIAGRAM**

(shown with AutoFlush® with cover removed)

**! WARNING**

**ALL DRAWINGS FOR ILLUSTRATIVE PURPOSES ONLY.**

Some components may be omitted or altered for clarity. Do not use for wiring, plumbing, repair or other purposes not related to component identification.



**REPLACEMENT PARTS LIST**

Part No.	Description	Generator
103036	Manual Drain Valve	All Models
99297	Safety Valve 15PSI	All Models
100479	Water Feed Solenoid Valve w/filter	All Models
100477-3	Transformer 24VAC	All Models
104724	Circuit Board	All Models
103904	Tandem Cable for 2 generators (12 ft.)	All Models
103917	Tandem Cable for up to 5 generators (30 ft.)	All Models
104678-60	60ft Control Cable	All Models
MSTS-30	Remote Temperature Probe (integral 30ft cable)	All Models
103660	Fuse block 2-pole	All Models
104415	Power Block 175A	All 1-Phase Models (except MX6R 208V)
104419	Power Block 270A	MX6R-Phase 208V
104015	Express Steam Thermostat	All Express Models

Part No.	Description	Generator
103453	Contactor 50A 4-pole	All 1-Phase Models
104423	Liquid Level Probe	All Models
99096MX	Heating Element Gasket	All Models
103938RD	Acrylic Shield for Round Steamhead	All Models
103938SQ	Acrylic Shield for Square Steamhead	All Models
99314	Power Fuse 60A 250V	All Models
29201BMS	Heating Element 20 KW 208V Single Phase	MX4R
29201CMS	Heating Element 20 KW 240V Single Phase	MX4R
29241BMS	Heating Element 24 KW 208V Single Phase	MX5R
29241CMS	Heating Element 24 KW 240V Single Phase	MX5R
29301BMS	Heating Element 30 KW 208V Single Phase	MX6R
29301CMS	Heating Element 30 KW 240V Single Phase	MX6R
104019	Heating Element for Express Steam	All Express Models

All drawing are for illustrative purposes only