

TRANSFORMERS

CONTROL TRANSFORMERS (CLASS 2 POWER LIMITING)



Control Transformers (OEM Mount) – CONTINUED

PART NO	PRIMARY VOLTAGE (V)	SECONDARY VOLTAGE (V)	CAPACITY (VA)	FREQ (HZ)	FOUR HOLE SPACING (IN)	OVERCURRENT PROTECTION	ELECTRICAL CONNECTIONS	POWER LIMITING
46-22863-05	230	24	40	50,60	2-3/16 x 1-3/4	2A Ext Fuse	Leads with 1/4 in. insulated female quick connects	Class 2
46-25107-08	460	24	40	50,60	1-3/16 x 1-1/2	—	Leads with stripped ends	Class 2
46-23115-03	460	24	50	50,60	1-7/8 x 1-1/2	—	Leads with stripped ends	Class 2
46-101659-02	208,230	24	40	50,60	1-7/8 x 1-1/2	—	Leads with stripped ends	Class 2
46-23115-02	208,230	24	40	50,60	1-7/8 x 1-1/2	—	Leads with stripped ends	Class 2



Control Transformers (Channel Mount – Two Hole)

PART NO	PRIMARY VOLTAGE (V)	SECONDARY VOLTAGE (V)	CAPACITY (VA)	FREQ (HZ)	FOUR HOLE SPACING (IN)	OVERCURRENT PROTECTION	ELECTRICAL CONNECTIONS	POWER LIMITING
46-24124-06	120	24	40	60	2-13/16	—	Leads with 1/4 in. insulated female quick connects	Class 2
46-101944-02	120	24	40	60	2-13/16	—	1/4 in. male quick connects	Class 2
46-25107-02	120	24	40	50,60	3-1/8	—	Leads with stripped ends	Class 2
46-102856-02	120	24	50	60	2-3/8	—	Leads with 1/4 in. insulated female quick connects	Class 2
46-25107-09	120	24	50	50,60	3-1/8	—	Leads with stripped ends	Class 2
46-25107-04	120,208,230	24	40	50,60	3-1/8	—	Leads with stripped ends	Class 2
46-25107-12	120,208,230,460	24	75	50,60	3-1/8	—	Leads with stripped ends	Class 2
46-101905-01	208,230	24	40	60	2-13/16	—	1/4 in. male quick connects	Class 2
46-103324-01	208,230	24	40	50,60	3-1/8	—	1/4 in. male quick connects primary 3/16 in. male quick connects secondary	Class 2
46-100836-01	208,230	24	40	50,60	3-1/8	2A External Fuse	Leads with 1/4 in. insulated female quick connects	Class 2
46-25107-03	208,230	24	40	50,60	3-1/8	—	Leads with stripped ends	Class 2
46-101944-03	208,230	24	50	60	2-13/16	—	1/4 in. male quick connects	Class 2
46-100836-05	208,230	24	50	50,60	3-1/8	3A External Fuse	Leads with 1/4 in. insulated female quick connects primary	Class 2
46-101904-02	208,230	24	50	50,60	3-1/8	—	Leads with stripped ends and 1/4 in. female quick connects	Class 2
46-103324-04	208,230	24	50	50,60	3-5/16	—	1/4 in. male quick connects primary 3/16 in. male quick connects secondary	Class 2
46-42515-01	208,230	24	75	50,60	3-9/16	3.2A Circuit Breaker	1/4 in. male quick connects	Class 2
46-41930-01	208,230,460	24	50	60	3-1/8	—	Leads with stripped ends	Class 2
46-41898-01	208,230,460	24	75	50,60	3-9/16	—	Leads with stripped ends	Class 2
46-101505-01	230	24	10	60	2-3/8	—	3/16 in. male quick connects	Class 2
46-100836-04	380-415	24	40	50,60	3-1/8	2A External Fuse	Leads with 1/4 in. female quick connects	Class 2
46-101946-01	460	24	40	50,60	2-13/16	—	1/4 in. male quick connects	Class 2
46-103324-02	460	24	40	50,60	3-1/8	—	1/4 in. male quick connects primary 3/16 in. male quick connects secondary	Class 2
46-103395-05	460	24	50	50,60	3-1/8	—	1/4 in. male quick connects primary 3/16 in. male quick connects secondary	Class 2
46-102027-01	460,575	24	50	50,60	3-1/8	3A External Fuse	Leads with 1/4 in. female quick connects	Class 2
46-42515-02	460,575	24	75	60	3-9/16	3.2A Circuit Breaker	1/4 in. male quick connects	Class 2
46-103324-03	575	24	40	50,60	3-1/8	—	1/4 in. male quick connects primary 3/16 in. male quick connects secondary	Class 2
46-42222-01	575	24	75	50,60	3-9/16	—	Leads with stripped ends	Class 2