





**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	52403	Lid & Kickstand Asm.
2	33908	Screw, #3-24 x 1/2" (4)
3	49163	Nut
4	49168	Flat Washer
5	49078	Keypad
6	33848	Bulkhead
7	34163	Ground Terminal
8	91767	Hex Nut (2)
9	52418	Battery Plate
10	52958	Screw, #4-20 x 1/2" (2)
11	59848	Battery Socket
12	52953	Screw, #4-40 x 1/8" (2)
13	52963	Screw, #4-20 x 1" (2)
14	52968	Washer (2)
15	52323	Rear Case Asm
16	34148	Ratchet Kickstand
17	34118	Wave Washer (2)
18	34113	Retaining Ring (2)
Item Not Shown		
	63893	Rear Interconnect Board



**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	49068	Front Connector Cover w/Pin
2	61423	Front Case (Less Keypad)
3	49078	Keypad
4	49083	Foam Seal
5	61413	DC Jack Asm
6	49088	Speaker Asm
7	49093	Audio PCB
8	60003	Wi-Fi Antenna Mount
9	49118	Screw, #4 X 1/2" (4)
10	52308	Screw, #2 X 3/8" (4)
11	32208	Screw, #2-28 X 1/4" (5)
12	59863	USB Connector PCB