




**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	49068	Front Connector Cover W/Pin
2	55343	Left Mount Bracket
3	55638	Washer
4	55633	Screw #8-32 x 5/16" (4)
5	49083	Foam Seal
6	52318	Front Cover Asm (Incl #'s 1-5,7, 8, 10, 11, 12)
7	52308	Screw, #2 x 3/8" (4)
8	49278	USB Connector Board
9	49118	Screw, #4 x 1/2" (4)
10	32208	Screw, #2 x 1/4" (5)
11	49093	Audio PCB Asm.
12	49088	Speaker Asm.