




**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

<u>Ref. No.</u>	<u>Catalog No.</u>	<u>Description</u>
1	49068	Front Connector Cover W/Pin
2	55343	Left Mount Bracket
3	55638	Washer
4	55633	Screw #8-32 x $\frac{5}{16}$ " (4)
5	49083	Foam Seal
6	52318	Front Cover Asm (Incl #'s 1-5,7, 8, 10, 11, 12)
7	52308	Screw, #2 x $\frac{3}{8}$ " (4)
8	49278	USB Connector Board
9	49118	Screw, #4 x $\frac{1}{2}$ " (4)
10	32208	Screw, #2 x $\frac{1}{4}$ " (5)
11	49093	Audio PCB Asm.
12	49088	Speaker Asm.