






**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	52408	Internal Foam Seal
2	33268	Screw, #8-32 x $\frac{3}{8}$ " (4)
3	48143	Handle Asm (Incl. Ref #4)
4	24288	Screw, #6 x $\frac{5}{8}$ " (6)
5	52318	Front Case Only




**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	52403	Lid & Kickstand Asm.
2	33908	Screw, #3-24 x 1/2" (4)
3	49163	Nut
4	49168	Flat Washer
5	49078	Keypad
6	33848	Bulkhead
7	34163	Ground Terminal
8	91767	Hex Nut (2)
9	52418	Battery Plate
10	52958	Screw, #4-20 x 1/2" (2)
11	49183	Battery Socket
12	52953	Screw, #4-40 x 1/2" (2)
13	52963	Screw, #4-20 x 1" (2)
14	52968	Washer (2)
15	52323	Rear Case Asm
16	34148	Ratchet Kickstand
17	34118	Wave Washer (2)
18	34113	Retaining Ring (2)



**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	49068	Front Connector Cover W/Pin
2	55343	Left Mount Bracket
3	55638	Washer
4	55633	Screw #8-32 x 5/16" (4)
5	49083	Foam Seal
6	52318	Front Cover Asm (Incl #'s 1-5, 7, 8, 10, 11, 12)
7	52308	Screw, #2 x 3/8" (4)
8	49278	USB Connector Board
9	49118	Screw, #4 x 1/2" (4)
10	32208	Screw, #2 x 1/4" (5)
11	49093	Audio PCB Asm.
12	49088	Speaker Asm.




**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1*	49198	LCD Assembly (Type 1)
	51798	LCD Assembly (Type 2)
2*	49208	Processor Board (Type 1)
	54668	Processor Board (Type 2)
3	31343	Screw, #4 x 1/4" (4)
4	54663	Camera Interface Board (Type 1 Only)
5	49118	Screw, #4 x 1/2" (4)
FOLLOWING ITEM NOT SHOWN		
	55813	LCD Connector Clamp


* LCD Mounting Plate For Type 1 LCD Has 5 Holes.
Type 2 Mounting Plate Has 4 Holes.

Processor Board Must Be Replaced At Factory Service Center



**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	52408	Internal Foam Seal
2	33268	Screw, #8-32 x 3/8" (4)
3	48143	Handle Asm (Incl. Ref #4)
4	24288	Screw, #6 x 5/8" (6)
5	52318	Front Case Only



**NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.**

Ref. No.	Catalog No.	Description
1	52403	Lid & Kickstand Asm.
2	33908	Screw, #3-24 x 1/2" (4)
3	49163	Nut
4	49168	Flat Washer
5	49078	Keypad
6	33848	Bulkhead
7	34163	Ground Terminal
8	91767	Hex Nut (2)
9	52418	Battery Plate
10	52958	Screw, #4-20 x 1/2" (2)
11	59848	Battery Socket
12	52953	Screw, #4-40 x 1/2" (2)
13	52963	Screw, #4-20 x 1" (2)
14	52968	Washer (2)
15	52323	Rear Case Asm
16	34148	Ratchet Kickstand
17	34118	Wave Washer (2)
18	34113	Retaining Ring (2)
Item Not Shown		
	63893	Rear Interconnect Board