

Williams Top Vent Gas-Fired Wall Furnace

REPLACEMENT PARTS FOR MODELS 5008731; 5008732; 5508331; 5508332; 6508731 AND 6508732

REF. NO.	DESCRIPTION	PART NO. FOR MODEL:					
		5008731	5008732	5508331	5508332	6508731	6508732
1	Outer Casing, Less Front Panel	7C55-4	7C55-4	7C55-3	7C55-3	7C55-3	7C55-3
2	Inner Liner	11B46	11B46	7B79	7B79	7B79	7B79
3	Heating Element	7C69	7C69	7C68	7C68	7C54-3	7C54-3
4	Relief Opening Pan	7D10	7D10	7D10	7D10	7D09	7D09
5	Top Front Panel	7B126	7B126	7B126	7B126	7B126	7B126
6	Center Front Panel	11C60	11C60	11C59	11C59	11C59	11C59
7	Switch Box	11B05	11B05	11B05	11B05	11B05	11B05
8	Limit Switch	P200300	P200300	P296001	P296001	P200300	P200300
9	Selector Switch	P213400	P213400	P296201	P296201	P296201	P296201
10	Fan Switch	P200200	P200200	P200200	P200200	P200200	P200200
11	Bottom Front Panel	11B103	11B103	11B103	11B103	11B103	11B103
12	Element Base Gasket	P026500	P026500	P026500	P026500	P026500	P026500
13	Fan Shroud	7B106	7B106	7B106	7B106	7B106	7B106
14	Relief Pan Gasket	P028300	P028300	P028300	P028300	P028300	P028300
15	Vent Cover	7B12	7B12	7B12	7B12	7B12	7B12
16	Header Gasket (3 Req.)	7A68	7A68	7A68	7A68	7A68	7A68
17	Flue Collar Gasket	P027100	P027100	P027100	P027100	P027100	P027100
18	Header	7B114	7B114	7B57	7B57	7B57	7B57
19	Limit Switch	P321127	P321127	P321127	P321127	P321127	P321127
20	Switch Box Cover	11C68	11C68	11C68	11C68	11C68	11C68
21	Lower Element Base Angle	7A117	7A117	7A117	7A117	7A117	7A117
22	Transformer, 115V/24V	P024200	P024200	P024200	P024200	P024200	P024200
23	Junction Box	7B29	7B29	7B29	7B29	7B29	7B29
24	Internal Wires (All Except Ign. Control)	5008731	5008732	5508331	5508332	6508731	6508732
25	Vibration Isolators (4 Req.)	P022800	P022800	P022800	P022800	P022800	P022800
26	Motor Support (2 Req.)	7B46	7B46	7B46	7B46	7B46	7B46
27	Motor	P062101	P062101	P062101	P062101	P321601	P321601
28	Fan Blade	P200600	P200600	P200600	P200600	P014300	P014300
29	Deflector Baffle Handle	11C63	11C63	11C63	11C63	11C63	11C63
30	★ Vent Enclosure Side (2 Req.)	9812	9812	9812	9812	9812	9812
31	★ Vent Enclosure Front						
30	★ Vent Enclosure Side (2 Req.)	9824	9824	9824	9824	9824	9824
31	★ Vent Enclosure Front						
32	★ Rear Grille, Two-Way						
33	★ Rear Outer Boot, 10" Long						
34	★ Plaster Ground	6801	6801	6801	6801	6801	6801
35	★ Rear Inner Boot, 10-3/4" Long						
36	★ Damper						
32	★ Rear Grille, Two-Way						
33	★ Rear Outer Boot, 7/8" Long						
34	★ Plaster Ground	6802	6802	6802	6802	6802	6802
35	★ Rear Inner Boot, 1-5/8" Long						
36	★ Damper						
37	★ Diffusing Grille Kit (Two-Way)	6703	6703	6703	6703	6703	6703
37	★ Diffusing Grille Kit (One-Way)	6704	6704	6704	6704	6704	6704

NOTE: Screws and bolts are standard hardware items, available locally.

★ Not available separately, in kit form only.

For parts illustration see pages 43 and 44.